



KEY NOTES

1. MOUNT A5145, HOOK, AT 1372 [4'-6"] AFF. PROVIDE 2-A5145'S FOR NAVY PROJECTS ONLY.
MOUNT 1-A5145 AT 1372 [4'-6"] AFF AND 1-A5145 AT 1524 [5'-0"] AFF.
2. COORDINATE LOCATION OF M1620, PATIENT CHART HOLDER, AND ROOM SIGNAGE.
3. M4200, OTOSCOPE/OPHTHALMOSCOPE, IS OPTIONAL.
4. THE ACCEPTABLE RANGE FROM M5600, CHAIR, TO M5562, VISUAL ACUITY TESTER, IS 3048 [10'-0"] TO 6096 [20'-0"].
5. P3200, UTR ELECTRONIC LAVATORY, MAY BE USED INSTEAD OF P3100, LAVATORY. FOR THE P3200 PROVIDE EITHER BATTERY POWER OR HARD WIRED CONNECTION.
6. IF EQUIPMENT POLE IS MOUNTED ON THE M5016, REFRACTION DESK, INSTEAD OF BESIDE M5600, CHAIR, M5016 MAY NEED TO BE RELOCATED.

EYE LANE-FOLDED ELECTRONIC (EYEL4)

OPHTHALMOLOGY/OPTOMETRY

FLOOR/EQUIPMENT PLAN 13.01 NSM (140 NSF)

DATE: 07/12/2001

0 1000 2000



1:50 SCALE (MILLIMETERS)